



EPILATORS : DRY USE

www.rowenta.com 1800138394

Please read these instructions carefully before using the appliance.

CAUTION: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

These instructions are also available on our website www.rowenta.com

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

sur les zones à risques (varices, grains de beauté, marque de naissance). si vous souffrez d'affections cutanées (eczéma, inflammations, acné). En cas d'usage sur la zone bikini, cet appareil est à utiliser uniquement pour le contour externe. Ne pas utiliser sur les zones les plus intimes (lèvres pubiennes). Pour des raisons d'hygiène, nous vous recommandons de ne pas prêter votre appareil même dans votre environnement proche.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

Peeling (Afhangigt af model) We empfehlen Ihnen, die Peelings 2 Tage nach der Epilation zu verwenden, um Ihre Haut nicht zu sehr zu irritieren.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

Lees de instructies vóórdat u het apparaat gaat gebruiken en vermijd gevaarlijke situaties als gevolg van een verkeerd gebruik.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

Garantía Su aparato está diseñado para un uso exclusivamente doméstico. Por tanto, no debe utilizarse para fines profesionales. La garantía quedará anulada si no se utiliza en caso de uso incorrecto.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

Μη χρησιμοποιείτε σύστημα τροφοδότησης διαφορετικό από το μοντέλο που παρέχεται από τον κατασκευαστή. Αποσυνδέστε τη συσκευή μετά τη χρήση, πριν από το καθαρισμό, σε περίπτωση βουλετοχυγίας. Για να αποσυνδέσετε τη συσκευή, τραβήξτε το βύσμα και όχι το καλώδιο. Μη χρησιμοποιείτε καλώδια επέκτασης. Μη φέρνετε τη συσκευή σε επαφή με τα ρούχα. Μη χρησιμοποιείτε τη συσκευή αποτήρυγης - στο πρόσωπο, στις βλεφαρίδες ή στα μαλλιά. - σε τραυματισμένο δέρμα. - σε επικίνδυνες περιοχές (κίρσοι, ελείες, σημάδια γήρανσης), - αν υποφέρετε από δερματικές παθήσεις (έκζεμα, φλεγμονές, ακμή). Αν την χρησιμοποιήσετε στο μπικினί, η συσκευή πρέπει να χρησιμοποιείται αποκλειστικά για το εξωτερικό περιγράμμο. Μην τη χρησιμοποιείτε σε πιο ευαίσθητες περιοχές (χειλί αιδού). Για λόγους υγιεινής, οι συσκευές να μην δανειζόεστε τη συσκευή, ακόμα και σε άτομα του στενού σας περιβάλλοντος.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

FORBEREDELSE AF HUDEN Husk altid varen ren og tør. Efter brug af apparatet: De må ikke berøre kroppen som dukker op på huden efter hårfjerningen og et bavis på håret før det fjernes. Fjern alle rester af produktet fra huden og kroppen. Det anbefales at bruge epilatoren om kvelden. Påse om nødvendigt en håndklæde eller hænder efter hårfjerningen.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

FORBEREDELSE AF HUDEN Husk altid varen ren og tør. Efter brug af apparatet: De må ikke berøre kroppen som dukker op på huden efter hårfjerningen og et bavis på håret før det fjernes. Fjern alle rester af produktet fra huden og kroppen. Det anbefales at bruge epilatoren om kvelden. Påse om nødvendigt en håndklæde eller hænder efter hårfjerningen.

Do not immerse or put under running water the appliance, even for cleaning purposes. The appliance must be powered only as per the voltage indicated on the power supply unit. Do not use any other power supply unit except that mentioned by the manufacturer.

Do not use extension cables. Ensure the appliance does not come into contact with clothes. Do not use the epilator: on the face, eyelashes or hair. on damaged skin areas. on areas which may present a health hazard (varicose veins, beauty spots, birthmarks).

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

PROTECTING THE ENVIRONMENT Your appliance contains valuable materials that can be recovered or recycled. Leave it at a waste collection point or an approved service centre so that it can be disposed of correctly.

Preparation of the skin Your skin must be clean and dry. Use dry skin the small red spots which appear after epilation show that hair has been removed correctly. They will disappear quickly. For this reason it is advisable to use the epilator at night. If necessary apply a soothing cream.

Waxing (according to model) We strongly recommend that you use the Epilator Head 2 days before using your epilator to avoid irritating your skin.

After using a peeling gel or cream at the same time. After peeling, we advise you to wipe over the area with a moist flannel to remove any dead skin.

Read the instructions carefully before using the epilator. The appliance is designed for domestic use only. It is not intended for professional use. The guarantee will be null and void if the appliance is used incorrectly.

